




INSTRUCTION MANUAL

Please read all instructions carefully. Improper handling and abuse of the product will void the warranty.

IMPORTANT

- ❖ Use a damp cloth or sponge to clean.
- ❖ Do not submerge the TOP COVER into water or wash under a running tap.
- ❖ Do not over fill the water container. Keep water just below the MAXIMUM line.
- ❖ Do not use any chemicals to clean the equipment, always use tap water only.
- ❖ In case of damaged power cord, DO NOT USE the Twister. Refer to your service agent immediately.
- ❖ Always disconnect power cord from electrical outlet before removing the TOP COVER or when the Twister is not in use.

This is How the Sirena Twister Works



DIRECTION OF USE



- (1)** Remove TOP COVER. Make sure funnel is secured properly



- (2)** Fill water container with clean water just below the MAXIMUM line



- (3)** Add recommended amount of fragrance concentrate into the water



- (4)** Replace TOP COVER. Make sure TOP COVER is securely seated on the container



- (5)** Plug in the electrical cord and turn on

CLEANING YOUR SIRENA TWISTER

Do not immerse in water! Do not clean in dishwasher! Wipe the top of the Sirena Twister inside and outside with a damp cloth only. Make sure to remove any dust and moisture.

Bowl - Rinse with clean cold water once a day before adding the concentrate.
Wipe the inside with a clean cloth or paper towel if dirty. Do not use abrasives or cleaning agents!

Funnel - Once a month unlock the funnel by holding the grey disc and turning the funnel counter-clockwise.
Lift the funnel away from the slots and rinse under cold water. Remove any dirt in the funnel with a cloth or brush.
Replace the funnel in the slots of the disc and turn clockwise until funnel locks into place.

WARRANTY

Go to Sirenasystem.com to Register your Warranty

The Sirena Twister is warrantied against manufacturer defect for a period of 1 (one) year from the date of purchase, Sirena may, at its sole discretion, fix or replace any Sirena Twister deemed to be defective.

Improper handling, abuse or failure to clean the revitalizer will deem the warranty void.

Fragrance concentrates are specially formulated for water air-purifiers and using any other liquid or substance will deem the warranty of your Sirena Twister null and void.

Use only Sirena approved liquids in your Sirena Twister.

The Sirena Twister should not get hot when in use. If it does, switch the unit off and contact your Sirena Twister supplier.

Please visit www.sirenasystem.com for more incredible Sirena products!



Register Your Warranty



Register Your Warranty

Sirena Inc

**11334 Boggy Creek Road Suite 107 Orlando, FL 32824
5459 Canotek Rd. Suite 1 Ottawa, ON, Canada K1J 9M3**

1-855-474-7362

1-613-695-6444